


Rev.2: 2014.08.12 Forg/Schnorr

HTPA32x31L10/1.0S

Thermopile Array With Lens Optics

Rev.2: 2014.08.12 Forg/Schnorr

Pin Assignment in TO8 – Bottom View:



Connect all reference voltages via 100 nF capacitors to VSS.

| Pin Assignment 32x31 | | | |
|----------------------|------------|-------------------------------|-------------------------|
| Pin | Name | Description | Type |
| 1 | MCLK | master clock | Digital Input |
| 2 | SCLK_IO | clock input/output for SPI | Digital Input/Output ** |
| 3 | SBY | Standby | Digital Input*** |
| 4 | VSAM | valid sample | Digital Output |
| 5 | DATA_IO | data input/output for SPI | Digital Input/Output ** |
| 6 | OUT_A2 | Analog Output | Analog Output |
| 7 | VCM_C | common mode voltage | Reference Voltage* |
| 8 | VREF_1225V | 1.225V reference voltage | Reference Voltage* |
| 9 | OUT_A1 | Analog Output | Analog Output |
| 10 | VSS | negative power supply voltage | Power |
| 11 | VDD | positive power supply voltage | Power |
| 12 | CONT | Control Pin for SPI | Digital Input |

*) Connect via 100 nF to VSS

**) The HTPA32x31 has no ADC, but the valid sample cycle number is delivered.

***) Connect to VSS or NC for internal reference voltages. Connect to VDD if VREF_1225V and VCM_C are applied from external. See “Application Note HTPA” for details.

Internal Register Map:

| Num | Name | Function | Default | Notes |
|-----|------|--------------------------|---------|--|
| 0 | R | Reset | 0 | In case of 1, the mux pixel counter is reset. ASIC stays in reset. |
| 1 | | spare | 1 | -not used- write '1' to this location |
| 2 | | spare | 0 | -not used- write '0' to this location |
| 3 | MA0 | Multiplexer address 0 | 0 | -not used- write '0' to this location |
| 4 | MA1 | Multiplexer address 1 | 0 | -not used- write '0' to this location |
| 5 | MA2 | Multiplexer address 2 | 0 | -not used- write '0' to this location |
| 6 | MA3 | Multiplexer address 3 | 0 | -not used- write '0' to this location |
| 7 | MA4 | Multiplexer address 4 | 0 | -not used- write '0' to this location |
| 8 | MA5 | Multiplexer address 5 | 0 | -not used- write '0' to this location |
| 9 | MA6 | Multiplexer address 6 | 0 | -not used- write '0' to this location |
| 10 | AIM | Automatic increment mode | 1 | 1 : auto increment mode 0: manual mode (not used) |
| 11 | AMPL | Amplification high bit | 0 | 0: low amplification 1: high amplification |
| 12 | | spare | 0 | -not used- write '0' to this location |
| 13 | | spare | 0 | -not used- write '0' to this location |
| 14 | | spare | 0 | -not used- write '0' to this location |
| 15 | BDUR | Break Duration | 0 | 0: 64clks of MCLK 1: 32clks of MCLK |

Order Code Example

| | | | | | | | |
|-----------|-----------|-------|----|---|-------|------|--|
| HTPA32x31 | L10 / 0.8 | F8-14 | Hi | M | (SPI) | [Si] | |
| | | | | | | | Type: HTPA32x31 Please contact support for all available HTPA and module combinations. |
| | | | | | | | Output: d Not declared HTPA sensor with digital output HTPA sensor with analogous output |
| | | | | | | | Optics: L / Focal length: In example L2,1 = 2,1 mm focal length F-Number: In example /0.85 For optics see also "HTPA standard optics" |
| | | | | | | | Filter: F Not declared Filter characteristics. In example F8-14 (µm, Bandpass) Broad band ARC |
| | | | | | | | Sensitivity: Hi Not declared Increased sensitivity Standard sensitivity |
| | | | | | | | Version: A M S Application set: comes with GUI, housing, power supply. Always UDP Interface. Module: HTPA sensor soldered to PCB, calibrated stream HTPA sensor only. Raw voltage output, not calibrated |
| | | | | | | | Interface: SPI LC UDP SPI device; Two variants: Analog HTPA, 14bit ADC Digital HTPA, 12bit ADC SPI,Only Analogous HTPA. low speed, external processing required Ethernet, CAT5 cable connection |
| | | | | | | | Lens Material: Si Not declared Silicon Germanium |

HTPA32x31L10/1.0S

Thermopile Array With Lens Optics

Rev.2: 2014.08.12 Forg/Schnorr



Characteristics:

Common Specifications:

| | |
|-----------------------------|---|
| Technology | n-poly/p-poly Si |
| Element Resistance | approx. 80 kOhms |
| Sensitivity | approx. 100 V/W without optics and filter |
| Thermal pixel time constant | <4 ms |
| MUX preamplifier noise | approx. 30 nV/ $\sqrt{\text{Hz}}$ |
| Pixel + amplifier noise | approx. 50 nV/ $\sqrt{\text{Hz}}$ |
| Digital Interface | SPI |
| Analog Output | Yes |
| 2 point selectable Gains | 880x / 2640 x |

| | |
|------------------------|-------------------|
| Pitch | 220 μm |
| Absorber size | 150 μm |
| Max. Framerate | 25 Hz |
| (without Averaging) | |
| 16 internal Amps + MUX | |
| 992 sensitive elements | |

Optical characteristics:

| | |
|----------------|---|
| Focal length: | 10 mm ("L" equals the focal length of the lens) |
| F-Number: | 1.0 |
| Field of view: | 39 x 38 deg |
| Lens coating: | AR-Coating; average reflectance per surface < 3% for $8\mu\text{m} < \lambda < 11.5 \mu\text{m}$ Environment acc. for MIL-C-48497 |

HTPA32x31L10/1.0S

Thermopile Array With Lens Optics

Rev.2: 2014.08.12 Forg/Schnorr



Electric Specifications:

Absolute Maximum Ratings:

| Parameter | Symbol | Condition | MIN. | TYP. | MAX. | Unit |
|-----------------------------------|------------------|-----------|------|------|----------------------|--------|
| Supply Voltage | V _{DD} | | -0.5 | | 6 | V |
| Voltage at All inputs and outputs | V _{IO} | | -0.5 | | V _{DD} +0.5 | V |
| Storage Temperature | T _{STG} | | -20 | | 85 | Deg. C |

Operating Conditions:

| Parameter | Symbol | Condition | MIN. | TYP. | MAX. | Unit |
|-----------------------|-----------------|------------------|------|------|------|--------|
| Supply Voltage | V _{DD} | | 4.5 | | 5.5 | V |
| Operation Temperature | T _A | | 0 | | 85 | Deg. C |
| ESD-Protection | | Human body model | 1.5 | | | kV |
| | | 100pF + 1k50hm | | | | |

Electrical Characteristics

| Parameter | Symbol | Condition | MIN. | TYP. | MAX. | Unit |
|-----------|--------|-----------|------|------|------|------|
|-----------|--------|-----------|------|------|------|------|

Digital Input

| | | | | | | |
|--------------------|-----------------|--|----------------------|----|-----|----|
| Frequency of MCLK | MCLK | | 100k | 1M | TBD | Hz |
| Input voltage high | V _{IH} | | V _{DD} -1.2 | | | V |
| Input voltage low | V _{IL} | | | | 1.2 | V |

PTAT

| | | | | | | |
|-------------------|--|--|------|------|------|--------|
| Temperature range | | | 0 | | 85 | Deg. C |
| PTAT gradient | | | 37.4 | 39.1 | 40.5 | K/V |

Signal Processing

| | | | | | | |
|--|---------------------|---------------------|-------|------|------|------|
| First amplifier stage gain | G0 | | TBD | 880 | TBD | V/V |
| Second amplifier stage gain | G1 | AMPL=0 | TBD | 1 | TBD | V/V |
| Second amplifier stage gain | G1 | AMPL=1 | TBD | 3 | TBD | V/V |
| Analog path 1 Output ripple | V _{PPSENS} | AMPL=0 MCLK=1MHz | 16 | 18 | 22 | mV |
| Analog path 2 Output ripple | V _{PPSENS} | AMPL=0 MCLK=1MHz | 64 | 69 | 74 | mV |
| Temp. coefficient Thermopile path output voltage | TCO _{OUTA} | | -0.07 | 0.02 | 0.10 | mV/K |

HTPA32x31L10/1.0S

Thermopile Array With Lens Optics

Rev.2: 2014.08.12 Forg/Schnorr



Electrical Characteristics (continued)

| Parameter | Symbol | Condition | MIN. | TYP. | MAX. | Unit |
|----------------------------------|-------------------|---|------|------|------|-------|
| VoltageReference | | | | | | |
| VREF_1225 | V _{REF} | V _{dd} =5V, T _{amb} =25°C SBY=1 | 1.31 | 1.32 | 1.34 | V |
| Temp. coeff. of V _{REF} | TC _{REF} | | 41 | 128 | 217 | ppm/K |

Analog Output


| | | | | | | |
|------------------------------|-------------------|--------------------------------|-------|-------|----------------------|----|
| Output voltage swing | V _{OUTA} | load 10kOhm | 0.5 | | V _{DD} -0.8 | V |
| Power supply rejection ratio | P _{SRR} | AMPL=0, VDD<5V MCLK=1MHz | -14.5 | -13.8 | -13.3 | dB |
| Output current limit | I _{OUTA} | OUT_A | 0.15 | | | mA |

General Parameters

| | | | | | | |
|-----------------------------|------------------|--------------------------------------|-----|------|-----|--------|
| Overall current consumption | I _{DD} | MCLK=1MHz 25° C | 7.1 | 7.4 | 8.2 | mA |
| Start up time | T _{POR} | Power On to first VSAM transition | | 1610 | | cycles |

Timings HTPA32x31:

Sample Timing HTPA32x31



For the HTPA32x31 every analogous voltage is stable in the whole time domain.


HTPA32x31L10/1.0S

Thermopile Array With Lens Optics

Rev.2: 2014.08.12 Forg/Schnorr

Serial Transmission:

HTPA32x31 Serial Transmission of analogue data



Off0...Off16 Electric offset of amplifier 0 to amplifier 16
Pix0...Pix991 Amplified pixel voltage of Pixel0 to Pixel991
PTAT0...PTAT7 PTAT-Signal

The numeration of the pixels is in all cases line by line.

HTPA32x31L10/1.0S

Thermopile Array With Lens Optics

Rev.2: 2014.08.12 Forg/Schnorr



SPI Communication:

Data sampled at rising edge of SCLK, MSB first.

In case of ASIC as master device the frequency of the SCLK_IO is equal to the frequency of MCLK/2.


The valid sample cycle numbers are expensed in the least 10 bits. The value runs from 0 to 527.

The output drivers for SCLK_IO and DATA_IO are enabled by CONT.


If CONT is low the data can be written serially from external controller through DATA_IO.

In that case the external controller has to wait a minimum delay time, until SCLK_IO and DATA_IO output drivers are disabled. After programming, the positive slope of CONT stores the contents, when the number of SCLK-pulses is equal 16. While the output driver of the ASIC is disabled a weak pull up ensures that the SCLK_IO pin is at high level. To execute a reset command, the μ C has to write a logical "1" to the R-Bit in to configuration and afterwards a "0" into the R-bit, which requires two write cycles in this special case.

Serial Read from ASIC



Serial Write to ASIC



HTPA32x31L10/1.0S


Thermopile Array With Lens Optics

Rev.2: 2014.08.12 Forg/Schnorr



Outer Dimensions:

HTPA32x31L10/1.0 (dual Germanium Spherical/Spherical lens combination, focal length 10mm):



HEIMANN Sensor GmbH Contact / Customer Support
Maria-Reiche-Str. 1 Phone 49 (0) 6123 60 50 30
D-01109 Dresden / Germany Fax 49 (0) 6123 60 50 39

Internet
www.heimannsensor.com
mail: info@heimannsensor.com