


1 Principal Schematic for HTPA16x16d:



HTPA16x16dL1.6/0.8_SMD

Thermopile Array With Lens Optics

Rev.0: 2016.05.04 Schnorr



2 Order Code Example

| HTPA32x31 | S | L10 / 0.8 | F8-14 | e | Hi | M | (SPD) | [Si] | |
|-----------|---|-----------|-------|---|----|---|-------|------|--|
| | | | | | | | | | Type: HTPA32x31 |
| | | | | | | | | | Please contact support for all available HTPA and module combinations. |
| | | | | | | | | | Package: S |
| | | | | | | | | | SMD variant |
| | | | | | | | | | Not declared TO can variant |
| | | | | | | | | | Output: d |
| | | | | | | | | | HTPA sensor with digital output |
| | | | | | | | | | Not declared HTPA sensor with analogous output |
| | | | | | | | | | Optics: L |
| | | | | | | | | | Focal length: In example L10 = 10.0 mm focal length |
| | | | | | | | | | / |
| | | | | | | | | | F-Number: In example /0.8 |
| | | | | | | | | | For optics see also "HTPA standard optics" |
| | | | | | | | | | Filter: F |
| | | | | | | | | | Filter characteristics. In example F8-14 (µm, Bandpass) |
| | | | | | | | | | Not declared Broad band ARC |
| | | | | | | | | | External aperture: Not declared |
| | | | | | | | | | without external aperture |
| | | | | | | | | | e |
| | | | | | | | | | with external aperture |
| | | | | | | | | | Sensitivity: Hi |
| | | | | | | | | | Increased sensitivity |
| | | | | | | | | | Not declared Standard sensitivity |
| | | | | | | | | | Version: A |
| | | | | | | | | | Application set: comes with GUI, housing, power supply. |
| | | | | | | | | | Always UDP Interface. |
| | | | | | | | | | C |
| | | | | | | | | | Calibrated sensor (only digital). Carries calibration constants on internal EEPROM |
| | | | | | | | | | M |
| | | | | | | | | | Module: HTPA sensor soldered to PCB, calibrated stream |
| | | | | | | | | | S |
| | | | | | | | | | HTPA sensor only. Raw voltage output, not calibrated |
| | | | | | | | | | Interface: SPI |
| | | | | | | | | | SPI device; Three variants: |
| | | | | | | | | | HTPA82x62: 16bit ADC |
| | | | | | | | | | all other analogous HTPAs: 14bit ADC |
| | | | | | | | | | Digital HTPA: 12bit ADC |
| | | | | | | | | | SPI, Only Analogous HTPA, 12bit ADC |
| | | | | | | | | | low speed, external processing required |
| | | | | | | | | | UDP |
| | | | | | | | | | Ethernet, CAT5 cable connection |
| | | | | | | | | | PoE |
| | | | | | | | | | Power over Ethernet, CAT5 connection, UDP protocol |
| | | | | | | | | | Lens Material: Si |
| | | | | | | | | | Silicon |
| | | | | | | | | | Not declared Germanium |

3 Serial Order of Frame

The sensor is divided into two parts (top and bottom half) which are again separated into 2 blocks. The readout order is shown below for the different blocks.

| |
|------------------|
| Block 0 (top) |
| Block 1 (top) |
| Block 1 (bottom) |
| Block 0 (bottom) |

Whenever a conversion is started the Block x of the top and bottom half are measured at the same time. Each block consists of 64 Pixel that are sampled fully parallel. The readout order on the bottom half is mirrored compared to the top half so that the central lines are always read last.

| | | | | | | | | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--|
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | readout order top ↓ readout order bottom |
| 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | |
| 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | |
| 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | |
| 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | |
| 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | |
| 96 | 97 | 98 | 99 | 100 | 101 | 102 | 103 | 104 | 105 | 106 | 107 | 108 | 109 | 110 | 111 | |
| 112 | 113 | 114 | 115 | 116 | 117 | 118 | 119 | 120 | 121 | 122 | 123 | 124 | 125 | 126 | 127 | |
| 128 | 129 | 130 | 131 | 132 | 133 | 134 | 135 | 136 | 137 | 138 | 139 | 140 | 141 | 142 | 143 | |
| 144 | 145 | 146 | 147 | 148 | 149 | 150 | 151 | 152 | 153 | 154 | 155 | 156 | 157 | 158 | 159 | |
| 160 | 161 | 162 | 163 | 164 | 165 | 166 | 167 | 168 | 169 | 170 | 171 | 172 | 173 | 174 | 175 | |
| 176 | 177 | 178 | 179 | 180 | 181 | 182 | 183 | 184 | 185 | 186 | 187 | 188 | 189 | 190 | 191 | |
| 192 | 193 | 194 | 195 | 196 | 197 | 198 | 199 | 200 | 201 | 202 | 203 | 204 | 205 | 206 | 207 | |
| 208 | 209 | 210 | 211 | 212 | 213 | 214 | 215 | 216 | 217 | 218 | 219 | 220 | 221 | 222 | 223 | |
| 224 | 225 | 226 | 227 | 228 | 229 | 230 | 231 | 232 | 233 | 234 | 235 | 236 | 237 | 238 | 239 | |
| 240 | 241 | 242 | 243 | 244 | 245 | 246 | 247 | 248 | 249 | 250 | 251 | 252 | 253 | 254 | 255 | |

The electrical offset is sampled parallel for the top and bottom half. The matching lines for the corresponding electrical offsets and active Pixel are marked with the same color.

| | | | | | | | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
| 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 |
| 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 |
| 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 |
| 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 |
| 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 |
| 96 | 97 | 98 | 99 | 100 | 101 | 102 | 103 | 104 | 105 | 106 | 107 | 108 | 109 | 110 | 111 |
| 112 | 113 | 114 | 115 | 116 | 117 | 118 | 119 | 120 | 121 | 122 | 123 | 124 | 125 | 126 | 127 |

4 Characteristics:

4.1 Common Specifications:

| | |
|-----------------------------|---|
| Technology | n-poly/p-poly Si |
| Element Resistance | approx. 300 kOhms |
| Sensitivity | approx. 450 V/W without optics and filter |
| Thermal pixel time constant | <4 ms |
| Digital Interface | I ² C |
| Analog Output | No |
| selectable Clock | 1 to 13 MHz |
| EEPROM size | 64 kBit |

| | |
|--|-------|
| Pitch | 90 µm |
| Absorber size | 77 µm |
| Max. Framerate | 60 Hz |
| (complete frame with maximum I ² C and sensor clock speed and reduced ADC resolution) | |
| 256 sensitive elements | |

4.2 Optical characteristics:

| | |
|----------------|--|
| Focal length: | 1.6 mm ("L" equals the focal length of the lens) |
| F-Number: | 0.8 |
| Field of view: | 53 x 53 deg |
| Lens coating: | AR-Coating; average reflectance per surface < 3% for $8\mu\text{m} < \lambda < 11.5\mu\text{m}$ Environment acc. for MIL-C-48497 |

4.3 Electric Specifications:

Absolute Maximum Ratings:

| Parameter | Symbol | Condition | MIN. | TYP. | MAX. | Unit |
|-----------------------------------|------------------|-----------|------|------|----------------------|--------|
| Supply Voltage | V _{DD} | | -0.3 | | 3.6 | V |
| Voltage at All inputs and outputs | V _{IO} | | -0.3 | | V _{DD} +0.3 | V |
| Storage Temperature | T _{STG} | | -40 | | 85 | Deg. C |

Operating Conditions:

| Parameter | Symbol | Condition | MIN. | TYP. | MAX. | Unit |
|---|------------------|------------------|------|------|------|--------|
| Supply Voltage | V _{DD} | | 3.3 | 3.35 | 3.6 | V |
| Supply Current (sensor running) | I _{DD} | | | TBD | | mA |
| Supply Current (sensor in idle state) | I _{DD} | | | TBD | | mA |
| Standby Current (sensor in sleep state) | I _{SBY} | | | TBD | | µA |
| Operation Temperature | T _A | | -20 | | 85 | Deg. C |
| ESD-Protection | | Human body model | 2.0 | | | kV |
| | | 100pF + 1k50hm | | | | |

Electrical Characteristics

| Parameter | Symbol | Condition | MIN. | TYP. | MAX. | Unit |
|-----------|--------|-----------|------|------|------|------|
|-----------|--------|-----------|------|------|------|------|

Digital Input

| | | | | | | |
|-----------------------------------|-------------------|--|---------------------|-----|---------------------|------|
| Internal Clock frequency | F _{CLK} | | 1 | 5 | 13 | MHz |
| Internal I ² C Pull up | R _{PU} | | 1 | 100 | 100 | kOhm |
| Bias current | I _{BIAS} | | 1 | 5 | 13 | µA |
| BPA current | I _{BPA} | | 0.2 | 1.5 | 4.0 | µA |
| Input voltage high | V _{IH} | | 0.7xV _{DD} | | | V |
| Input voltage low | V _{IL} | | | | 0.3xV _{DD} | V |

PTAT

| | | | | | | |
|-------------------|--|--|-----|-----|-----|--------|
| Temperature range | | | TBD | | TBD | Deg. C |
| PTAT gradient | | | | TBD | | K/V |

HTPA16x16dL1.6/0.8_SMD

Thermopile Array With Lens Optics


Rev.0: 2016.05.04 Schnorr



Preamplifier / ADC

| Parameter | Symbol | Condition | MIN. | TYP. | MAX. | Unit |
|-------------------------|---------------------------|-----------|------|------|------|----------------------|
| Chopper frequency | F_{CHP} | | | 20 | | kHz |
| Preamplifier Noise | N_{PA} | at 20 kHz | | 72 | | nV/HZ ^{1/2} |
| Frame rate (Full Array) | FR1 | | | 18 | | Hz |
| Frame rate (Half Array) | FR4 | | | 36 | | HZ |
| ADC pos. Reference | V_{REFP} | | | 1.6 | | V |
| ADC neg. Reference | V_{REFN} | | | 0.9 | | V |
| ADC resolution | ADC_{LSB} | at 16 Bit | | 21 | | μV |

5 I²C Timings HTPA16x16d:




| Parameter | Symbol | Condition | MIN. | TYP. | MAX. | Unit |
|----------------------------------|-----------------------|-----------|------|------|------|---------------|
| I ² C clock frequency | F_{CLK} | | | 400 | 1000 | kHz |
| low pulse duration | $T_{\text{CLK,lo}}$ | | 0.50 | | | μs |
| high pulse duration | $T_{\text{CLK,hi}}$ | | 0.26 | | | μs |
| data set up time | $T_{\text{SU,data}}$ | | 0.05 | | | μs |
| data hold time | $T_{\text{hd,data}}$ | | 0.00 | | | μs |
| start setup time | $T_{\text{SU,start}}$ | | 0.26 | | | μs |
| start hold time | $T_{\text{hd,start}}$ | | 0.26 | | | μs |
| stop setup time | $T_{\text{SU,stop}}$ | | 0.26 | | | μs |
| stop hold time | $T_{\text{hd,stop}}$ | | 0.26 | | | μs |
| time between STOP / START | T_{buf} | | 0.50 | | | μs |

6 I²C Communication:

The chip uses the 7-bit I²C address 0x34 for configuration and sensor data and the address 0xA0 to access the internal EEPROM. The address byte is followed by an 8-bit command.


6.1 Write Command:

In case of a write access to an internal register the command is followed by the data byte. The chip acknowledges each byte with a low active ACK bit.



6.2 Read Command:

To read data from the chip first the address and command must be sent. After the last ACK a new start-bit (repeated start) and the address with a set read-flag initiates the read sequence. There can be bytes read as many as required. The last byte must be denoted by a not-acknowledge. The shown example below can be used e.g. to get the status register.



6.3 Sensor Commands:

The sensor has several registers that can be written and read, they are listed below.

Configuration register (write only)

| Addr / CMD | 0x34 / 0x01 | | | | | | | |
|------------|-------------|---|-------|---|-------|-----|-------|--------|
| Config Reg | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Name | RFU | | BLOCK | | START | RFU | BLIND | WAKEUP |
| Default | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

The WAKEUP bit is used to switch on / off the chip and must be set prior all other operations. After the START bit is set the chip starts a conversion of the array or blind elements and enters the idle state (not sleep!) when finished. The BLOCK selects one of the four multiplexed array blocks.

If the BLIND bit is set the electrical offsets are sampled instead of the active pixel and the setting of the BLOCK is ignored.

Status Register (read only)

| Addr / CMD | 0x34 / 0x02 | | | | | | | |
|------------|-------------|---|---|---|-------|---|-----|-----|
| Status Reg | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Name | RFU | | | | BLOCK | | RFU | EOC |
| Default | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

If the EOC flag is set a previous started conversion has been finished.

HTPA16x16dL1.6/0.8_SMD

Thermopile Array With Lens Optics

Rev.0: 2016.05.04 Schnorr



Trim Register 1 (write only)

| | | | | | | | | |
|------------|-------------|---|---|---|-----------|---|---|---|
| Addr / CMD | 0x34 / 0x03 | | | | | | | |
| Trim Reg 1 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Name | RFU | | | | MBIT TRIM | | | |
| Default | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |

MBIT_TRIM: $m = 4$ to $12 \Rightarrow (m+4)$ bit as ADC resolution (Default: $m=12$)

Trim Register 2 (write only)

| | | | | | | | | |
|------------|-------------|---|---|---|---------------|---|---|---|
| Addr / CMD | 0x34 / 0x04 | | | | | | | |
| Trim Reg 2 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Name | RFU | | | | BIAS TRIM TOP | | | |
| Default | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |

BIAS_TRIM_TOP: 0 to 31 $\Rightarrow 1\mu\text{A}$ to $13\mu\text{A}$ (Default: $5\mu\text{A}$)

This setting is used to adjust the bias current of the ADC. A faster clock frequency requires a higher bias current setting.

Trim Register 3 (write only)

| | | | | | | | | |
|------------|-------------|---|---|---|---------------|---|---|---|
| Addr / CMD | 0x34 / 0x05 | | | | | | | |
| Trim Reg 3 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Name | RFU | | | | BIAS TRIM BOT | | | |
| Default | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |

BIAS_TRIM_BOT: 0 to 31 $\Rightarrow 1\mu\text{A}$ to $13\mu\text{A}$ (Default: $5\mu\text{A}$)

This setting is used to adjust the bias current of the ADC. A faster clock frequency requires a higher bias current setting.

Trim Register 4 (write only)

| | | | | | | | | |
|------------|-------------|---|---|---|----------|---|---|---|
| Addr / CMD | 0x34 / 0x06 | | | | | | | |
| Trim Reg 4 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Name | RFU | | | | CLK TRIM | | | |
| Default | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 1 |

CLK_TRIM: 0 to 63 $\Rightarrow 1\text{MHz}$ to 13MHz (Default: 5MHz)

NOTE: The measure time depends on the clock frequency settings. One quarter frame takes about:

$$t_{FR4} = \frac{32 \cdot (2^{MBIT} + 4)}{F_{CLK}} \approx 27\text{ms} @ 5\text{MHz}$$

Trim Register 5 (write only)

| | | | | | | | | |
|------------|-------------|---|---|---|--------------|---|---|---|
| Addr / CMD | 0x34 / 0x07 | | | | | | | |
| Trim Reg 5 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Name | RFU | | | | BPA TRIM TOP | | | |
| Default | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |

BPA_TRIM_TOP: 0 to 31 $\Rightarrow 0.2\mu\text{A}$ to $4.0\mu\text{A}$ (Default: $1.5\mu\text{A}$)

This setting is used to adjust the common mode voltage of the preamplifier.

Trim Register 6 (write only)

| | | | | | | | | |
|------------|-------------|---|---|---|--------------|---|---|---|
| Addr / CMD | 0x34 / 0x08 | | | | | | | |
| Trim Reg 6 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Name | RFU | | | | BPA TRIM BOT | | | |
| Default | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |

BPA_TRIM_BOT: 0 to 31 \Rightarrow 0.2 μ A to 4.0 μ A (Default: 1.5 μ A)

This setting is used to adjust the common mode voltage of the preamplifier.

Trim Register 7 (write only)

| | | | | | | | | |
|------------|-------------|---|---|---|-------------|---|---|---|
| Addr / CMD | 0x34 / 0x09 | | | | | | | |
| Trim Reg 7 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Name | PU SDA TRIM | | | | PU SCL TRIM | | | |
| Default | 1 | 0 | 0 | 0 | 1 | 0 | 0 | 0 |

PU_SDA_TRIM: select internal pull up resistor on SDA (Default: 100kOhm)

PU_SCL_TRIM: select internal pull up resistor on SCL (Default: 100kOhm)

“1000” = 100 kOhm; “0100” = 50 kOhm; “0010” = 10 kOhm; “0001” = 1 kOhm

Read Data 1 Command (Top Half of Array)

| | | | | | | | | |
|-----------------------|-------------------------------|---|---|---|---|---|---|---|
| Addr / CMD | 0x34 / 0x0A | | | | | | | |
| Read Data | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 1. Byte / 2. Byte | PTAT 1 MSB / LSB | | | | | | | |
| 3. Byte / 4. Byte | Pixel (0+BLOCK*64) MSB / LSB | | | | | | | |
| 5. Byte / 6. Byte | Pixel (1+BLOCK*64) MSB / LSB | | | | | | | |
| ... | ... | | | | | | | |
| 129. Byte / 130. Byte | Pixel (63+BLOCK*64) MSB / LSB | | | | | | | |

Read Data 2 Command (Bottom Half of Array)

| | | | | | | | | |
|-----------------------|--------------------------------|---|---|---|---|---|---|---|
| Addr / CMD | 0x34 / 0x0B | | | | | | | |
| Read Data | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 1. Byte / 2. Byte | PTAT 2 MSB / LSB | | | | | | | |
| 3. Byte / 4. Byte | Pixel (240-BLOCK*64) MSB / LSB | | | | | | | |
| 5. Byte / 6. Byte | Pixel (241-BLOCK*64) MSB / LSB | | | | | | | |
| ... | | | | | | | | |
| 33. Byte / 34. Byte | Pixel (255-BLOCK*64) MSB / LSB | | | | | | | |
| 35. Byte / 36. Byte | Pixel (224-BLOCK*64) MSB / LSB | | | | | | | |
| 37. Byte / 38. Byte | Pixel (225-BLOCK*64) MSB / LSB | | | | | | | |
| ... | | | | | | | | |
| 65. Byte / 66. Byte | Pixel (239-BLOCK*64) MSB / LSB | | | | | | | |
| 67. Byte / 68. Byte | Pixel (192-BLOCK*64) MSB / LSB | | | | | | | |
| ... | | | | | | | | |
| 129. Byte / 130. Byte | Pixel (207-BLOCK*64) MSB / LSB | | | | | | | |

The complete sensor data must be read at once. If the communication fails somewhere in between, all successive data will be corrupted. The readout can be stopped anywhere by pausing the clock. A new initialized readout proceeds at this stopped byte by continuing the clock, but the index is reset when a new conversion has been started.

HTPA16x16dL1.6/0.8_SMD

Thermopile Array With Lens Optics

Rev.0: 2016.05.04 Schnorr



If the bit for the electrical offsets (Bit 1 in Config 0x01) is set the electrical offsets are sampled and can be read similar to the active pixel:

Read Data electrical offsets (Top Half of Array)

| | | | | | | | | |
|-----------------------|----------------------------------|---|---|---|---|---|---|---|
| Addr / CMD | 0x34 / 0x0A | | | | | | | |
| Read Data | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 1. Byte / 2. Byte | PTAT 1 MSB / LSB | | | | | | | |
| 3. Byte / 4. Byte | electrical offset (0) MSB / LSB | | | | | | | |
| 5. Byte / 6. Byte | electrical offset (1) MSB / LSB | | | | | | | |
| ... | ... | | | | | | | |
| 129. Byte / 130. Byte | electrical offset (63) MSB / LSB | | | | | | | |

Read Data electrical offsets (Bottom Half of Array)

| | | | | | | | | |
|-----------------------|-----------------------------------|---|---|---|---|---|---|---|
| Addr / CMD | 0x34 / 0x0B | | | | | | | |
| Read Data | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 1. Byte / 2. Byte | PTAT 2 MSB / LSB | | | | | | | |
| 3. Byte / 4. Byte | electrical offset (112) MSB / LSB | | | | | | | |
| 5. Byte / 6. Byte | electrical offset (113) MSB / LSB | | | | | | | |
| ... | ... | | | | | | | |
| 33. Byte / 34. Byte | electrical offset (127) MSB / LSB | | | | | | | |
| 35. Byte / 36. Byte | electrical offset (96) MSB / LSB | | | | | | | |
| ... | ... | | | | | | | |
| 129. Byte / 130. Byte | electrical offset (79) MSB / LSB | | | | | | | |

The complete sensor data must be read at once. If the communication fails somewhere in between, all successive data will be corrupted. The readout can be stopped anywhere by pausing the clock. A new initialized readout proceeds at this stopped byte by continuing the clock, but the index is reset when a new conversion has been started.

6.4 EEPROM communication

TBD

6.5 I²C Example Sequences – Init and Read Thermopile Array

(There should be a delay of at least 5 ms between the write of each Configuration Register)

| | ADDR | R/W | CONFIG_REG | WAKEUP | |
|---|------|-----|------------|--------|---|
| S | 0x34 | 0 | 0x01 | 0x01 | P |

| | ADDR | R/W | TRIM_REG1 | MBIT_TRIM | |
|---|------|-----|-----------|-----------|---|
| S | 0x34 | 0 | 0x03 | 0x0C | P |

| | ADDR | R/W | TRIM_REG2 | BIAS_TRIML | |
|---|------|-----|-----------|------------|---|
| S | 0x34 | 0 | 0x04 | 0x0C | P |

| | ADDR | R/W | TRIM_REG3 | BIAS_TRIMR | |
|---|------|-----|-----------|------------|---|
| S | 0x34 | 0 | 0x05 | 0x0C | P |

| | ADDR | R/W | TRIM_REG4 | CLK_TRIM | |
|---|------|-----|-----------|----------|---|
| S | 0x34 | 0 | 0x06 | 0x14 | P |

| | ADDR | R/W | TRIM_REG5 | BPA_TRIML | |
|---|------|-----|-----------|-----------|---|
| S | 0x34 | 0 | 0x07 | 0x0C | P |

| | ADDR | R/W | TRIM_REG6 | BPA_TRIMR | |
|---|------|-----|-----------|-----------|---|
| S | 0x34 | 0 | 0x08 | 0x0C | P |

| | ADDR | R/W | TRIM_REG7 | PU_TRIM | |
|---|------|-----|-----------|---------|---|
| S | 0x34 | 0 | 0x09 | 0x88 | P |

| | ADDR | R/W | CONFIG_REG | START/WAKEUP | |
|---|------|-----|------------|--------------|---|
| S | 0x34 | 0 | 0x01 | 0x09 | P |

| | ADDR | R/W | STATUS_REG | | ADDR | R/W | STATUS | |
|---|------|-----|------------|----|------|-----|--------|---|
| S | 0x34 | 0 | 0x02 | Sr | 0x34 | 1 | ?? | P |

Wait 30 ms

| | ADDR | R/W | STATUS_REG | | ADDR | R/W | STATUS | |
|---|------|-----|------------|----|------|-----|--------|---|
| S | 0x34 | 0 | 0x02 | Sr | 0x34 | 1 | ?? | P |

| | ADDR | R/W | READ_DATA 1 | | ADDR | R/W | PTAT1 MSB | PTAT1 LSB | P0.0 MSB | P0.0 LSB | ... | Pxy MSB | Pxy LSB | |
|---|------|-----|-------------|----|------|-----|-----------|-----------|----------|----------|-----|---------|---------|---|
| S | 0x34 | 0 | 0x0A | Sr | 0x34 | 1 | ?? | ?? | ?? | ?? | ... | ?? | ?? | P |

| | ADDR | R/W | READ_DATA 2 | | ADDR | R/W | PTAT2 MSB | PTAT2 LSB | P0.0 MSB | P0.0 LSB | ... | Pxy MSB | Pxy LSB | |
|---|------|-----|-------------|----|------|-----|-----------|-----------|----------|----------|-----|---------|---------|---|
| S | 0x34 | 0 | 0x0B | Sr | 0x34 | 1 | ?? | ?? | ?? | ?? | ... | ?? | ?? | P |

| | ADDR | R/W | CONFIG_REG | SLEEP | |
|---|------|-----|------------|-------|---|
| S | 0x34 | 0 | 0x01 | 0x00 | P |

7 Temperature calculation

TBD

Preliminary

7.1 Ambient Temperature:

The ambient temperature (T_a) is calculated from the average measured PTAT value, the $PTAT_{gradient}$ and the $PTAT_{offset}$.

$$T_a = \frac{\sum_{i=0}^3 PTAT_i}{4} \cdot PTAT_{gradient} + PTAT_{offset} \quad (\text{Value is given back in dK})$$

where:

$PTAT_{gradient}$ is the gradient of the PTAT stored in the EEPROM as a float value

$PTAT_{offset}$ is the offset of the PTAT stored in the EEPROM as a float value

7.2 Thermal Offset:

The thermal offset of the sensor needs to be subtracted for each pixel to compensate for any thermal drifts.

$$V_{ij_Comp} = V_{ij} - \frac{ThGrad_{ij} \cdot T_a}{2^{gradScale}} - ThOffset_{ij}$$

where:

ij represents the row (i) and column (j) of the pixel

V_{ij_Comp} is the thermal offset compensated voltage

V_{ij} is the raw pixel data (digital), readout from the RAM

$ThGrad_{ij}$ is the thermal gradient, stored in the EEPROM from 0x740 to 0xF3F

$ThOffset_{ij}$ is the thermal offset, stored in the EEPROM from 0xF40 to 0x173F

$gradScale$ is the scaling coefficient for the thermal gradient

7.3 Electrical Offset

The electrical offset is used to compensate changes in the supply voltage. This compensation is only a subtraction so it can be done before or after the thermal offset compensation (here done afterwards).

The compensation for the top half is done by using the following formula:

$$V_{ij_Comp}^* = V_{ij_Comp} - elOffset[j + (i : 4) \cdot 32]$$

and the bottom half analogue with this formula:

$$V_{ij_Comp}^* = V_{ij_Comp} - elOffset[j + (i : 4) \cdot 32 + 128]$$

where:

ij represents the row (i) and column (j) of the pixel and electrical offset

$V_{ij_Comp}^*$ is the electrical offset compensated voltage

V_{ij_Comp} is the thermal offset compensated voltage

$elOffset[ij]$ is the electrical offset belonging to Pixel ij

$i : 4$ is the rest of the integer division of i by 4 (e.g. $7:4=3$)

Please see chapter 3 for the serial order.

7.4 Object Temperature:

The calculation of the object temperature is done by using a look-up table and doing a bi-linear interpolation, the matching table is given by the tablenumber (TN). The table is supplied in a separate file named "Table.c".

The sensitivity coefficients ($PixC_{ij}$) are calculated in the following way:

$$PixC_{ij} = \left(\frac{P_{ij} \cdot (PixC_{\max} - PixC_{\min})}{65535} + PixC_{\min} \right) \cdot \frac{100}{\epsilon}$$

where:

- $PixC_{ij}$ is the sensitivity coefficient for each pixel
- P_{ij} is the stored sensitivity coefficient scaled to 16 bit
- $PixC_{\min}$ is the minimum sensitivity coefficient, used for scaling
- $PixC_{\max}$ is the maximum sensitivity coefficient, used for scaling
- ϵ is the emissivity factor

Leading to a compensation of the pixel voltage

$$V_{ij_PixC} = \frac{V_{ij_Comp} \cdot PCSCALEVAL}{PixC_{ij}}$$

where:

- V_{ij_PixC} is the sensitivity compensated IR voltage
- $PCSCALEVAL$ is a scaling coefficient, typically $1 \cdot 10^8$

7.5 Example calculation:

Example values:

$$PTAT = 32357 \text{ Digits}$$

$$PTAT_{\text{gradient}} = 0.046 \text{ dK / Digit}$$

$$PTAT_{\text{offset}} = 1511.6 \text{ dK}$$

$$V_{00} = 34435 \text{ Digits}$$

$$\text{gradScale} = 15$$

$$ThGrad_{00} = 56693 \xrightarrow{\text{sign check}} -8842$$

$$ThOffset_{00} = 44$$

$$elOffset[0] = 35000$$

$$PixC_{00} = 1.1 \cdot 10^8$$

$$PCSCALEVAL = 1 \cdot 10^8$$

Calculation of ambient temperature:

$$Ta = PTAT \cdot PTAT_{\text{gradient}} + PTAT_{\text{offset}} = 32357 \cdot 0.046 + 1511.6 \text{ dK} = 3000 \text{ dK}$$

Compensation of thermal offset:

$$V_{00_Comp} = V_{00} - \frac{ThGrad_{00} \cdot Ta}{2^{\text{gradScale}}} - ThOffset_{00} = 34435 - \frac{-8842 \cdot 3000}{2^{15}} - 44 = 35200$$

Compensation of electrical offset:

$$V_{00_Comp}^* = V_{00_Comp} - elOffset[0] = 35200 - 35000 = 200$$

HTPA16x16dL1.6/0.8_SMD

Thermopile Array With Lens Optics

Rev.0: 2016.05.04 Schnorr



Example look-up table:

| TA[dK]/dig | 2882 | 3032 | 3182 | 3332 |
|------------|------|------|------|------|
| -64 | 1494 | 2128 | 2491 | 2775 |
| -32 | 2466 | 2692 | 2898 | 3091 |
| 0 | 2882 | 3032 | 3182 | 3332 |
| 32 | 3170 | 3285 | 3406 | 3530 |
| 64 | 3396 | 3491 | 3592 | 3699 |
| 96 | 3584 | 3665 | 3754 | 3848 |
| 128 | 3746 | 3818 | 3897 | 3981 |
| 160 | 3890 | 3954 | 4025 | 4102 |
| 192 | 4019 | 4078 | 4143 | 4214 |
| 224 | 4137 | 4191 | 4251 | 4317 |
| 256 | 4246 | 4296 | 4351 | 4413 |
| 288 | 4347 | 4393 | 4445 | 4503 |
| 320 | 4441 | 4485 | 4534 | 4588 |

$$V_{00_PixC} = \frac{200 \cdot 1 \cdot 10^8}{1.1 \cdot 10^8} = 182$$

Ta was calculated before to 3000 dK.

The matching region in the look-up table is already marked yellow, the bi-linear interpolation is leading to an object temperature of 3941 dK = 120.9 °C.

HTPA16x16dL1.6/0.8_SMD

Thermopile Array With Lens Optics

Rev.0: 2016.05.04 Schnorr



7.6 Look-up Table

| dig \ T _a (dK) | 2782 | 2882 | 2982 | 3082 | 3182 | 3282 | 3382 |
|---------------------------|------|------|------|------|------|------|------|
| -256 | | | | 1159 | 1804 | 2115 | 2343 |
| -192 | | | | 2211 | 2407 | 2576 | 2727 |
| -128 | | | | 2605 | 2742 | 2872 | 2995 |
| -64 | | | | 2873 | 2986 | 3097 | 3206 |
| 0 | 2782 | 2882 | 2982 | 3082 | 3182 | 3282 | 3382 |
| 64 | 2993 | 3078 | 3166 | 3256 | 3347 | 3440 | 3534 |
| 128 | 3167 | 3243 | 3322 | 3405 | 3491 | 3579 | 3669 |
| 192 | 3316 | 3385 | 3459 | 3537 | 3619 | 3703 | 3790 |
| 256 | 3448 | 3512 | 3582 | 3656 | 3734 | 3816 | 3901 |
| 320 | 3565 | 3626 | 3693 | 3764 | 3840 | 3920 | 4003 |
| 384 | 3673 | 3731 | 3794 | 3864 | 3938 | 4016 | 4097 |
| 448 | 3771 | 3827 | 3889 | 3956 | 4029 | 4105 | 4186 |
| 512 | 3863 | 3916 | 3977 | 4043 | 4114 | 4189 | 4269 |
| 576 | 3948 | 4000 | 4059 | 4124 | 4194 | 4269 | 4348 |
| 640 | 4028 | 4079 | 4137 | 4200 | 4270 | 4344 | 4423 |
| 704 | 4104 | 4154 | 4210 | 4273 | 4342 | 4415 | 4494 |
| 768 | 4176 | 4224 | 4280 | 4342 | 4410 | 4484 | 4561 |
| 832 | 4244 | 4292 | 4346 | 4408 | 4476 | 4549 | 4626 |
| 896 | 4309 | 4356 | 4410 | 4471 | 4538 | 4611 | 4689 |
| 960 | 4371 | 4417 | 4471 | 4532 | 4599 | 4671 | 4748 |
| 1024 | 4431 | 4476 | 4530 | 4590 | 4657 | 4729 | 4806 |
| 1088 | 4488 | 4533 | 4586 | 4646 | 4713 | 4785 | 4862 |
| 1152 | 4543 | 4588 | 4641 | 4700 | 4767 | 4839 | 4916 |
| 1216 | 4597 | 4641 | 4693 | 4753 | 4819 | 4891 | 4968 |
| 1280 | 4648 | 4692 | 4744 | 4803 | 4869 | 4941 | 5018 |
| 1344 | 4698 | 4742 | 4793 | 4852 | 4918 | 4990 | 5068 |
| 1408 | 4746 | 4790 | 4841 | 4900 | 4966 | 5038 | 5115 |
| 1472 | 4793 | 4836 | 4888 | 4946 | 5012 | 5084 | 5162 |
| 1536 | 4839 | 4881 | 4933 | 4991 | 5057 | 5129 | 5207 |
| 1600 | 4883 | 4926 | 4977 | 5035 | 5101 | 5173 | 5251 |
| 1664 | 4926 | 4969 | 5019 | 5078 | 5144 | 5216 | 5294 |
| 1728 | 4968 | 5010 | 5061 | 5120 | 5185 | 5258 | 5336 |
| 1792 | 5009 | 5051 | 5102 | 5160 | 5226 | 5299 | 5377 |
| 1856 | 5049 | 5091 | 5142 | 5200 | 5266 | 5338 | 5417 |
| 1920 | 5088 | 5130 | 5180 | 5239 | 5305 | 5377 | 5456 |
| 1984 | 5126 | 5168 | 5218 | 5277 | 5343 | 5416 | 5494 |
| 2048 | 5164 | 5205 | 5256 | 5314 | 5380 | 5453 | 5532 |
| 2112 | 5200 | 5242 | 5292 | 5351 | 5417 | 5490 | 5569 |
| 2176 | 5236 | 5277 | 5328 | 5386 | 5453 | 5526 | 5605 |
| 2240 | 5271 | 5312 | 5363 | 5421 | 5488 | 5561 | 5640 |
| 2304 | 5305 | 5347 | 5397 | 5456 | 5522 | 5595 | 5675 |
| 2368 | 5339 | 5380 | 5431 | 5490 | 5556 | 5629 | 5709 |
| 2432 | 5372 | 5413 | 5464 | 5523 | 5589 | 5663 | 5742 |
| 2496 | 5405 | 5446 | 5496 | 5555 | 5622 | 5695 | 5775 |
| 2560 | 5437 | 5478 | 5528 | 5587 | 5654 | 5728 | 5808 |
| 2624 | 5468 | 5509 | 5559 | 5618 | 5685 | 5759 | 5840 |
| 2688 | 5499 | 5540 | 5590 | 5649 | 5716 | 5790 | 5871 |
| 2752 | 5529 | 5570 | 5621 | 5680 | 5747 | 5821 | 5902 |
| 2816 | 5559 | 5600 | 5651 | 5710 | 5777 | 5851 | 5932 |
| 2880 | 5588 | 5629 | 5680 | 5739 | 5806 | 5881 | 5962 |
| 2944 | 5617 | 5658 | 5709 | 5768 | 5836 | 5910 | 5992 |
| 3008 | 5646 | 5687 | 5737 | 5797 | 5864 | 5939 | 6021 |
| 3072 | 5674 | 5715 | 5765 | 5825 | 5893 | 5968 | 6049 |
| 3136 | 5701 | 5742 | 5793 | 5853 | 5920 | 5996 | 6078 |
| 3200 | 5729 | 5770 | 5820 | 5880 | 5948 | 6023 | 6105 |
| 3264 | 5756 | 5797 | 5847 | 5907 | 5975 | 6051 | 6133 |
| 3328 | 5782 | 5823 | 5874 | 5934 | 6002 | 6078 | 6160 |
| 3392 | 5808 | 5849 | 5900 | 5960 | 6028 | 6104 | 6187 |
| 3456 | 5834 | 5875 | 5926 | 5986 | 6054 | 6130 | 6213 |
| 3520 | 5859 | 5900 | 5951 | 6012 | 6080 | 6156 | 6239 |
| 3584 | 5885 | 5926 | 5977 | 6037 | 6105 | 6182 | 6265 |
| 3648 | 5909 | 5950 | 6001 | 6062 | 6131 | 6208 | 6291 |
| 3712 | 5934 | 5975 | 6026 | 6086 | 6155 | 6232 | 6315 |
| 3776 | 5958 | 5999 | 6050 | 6111 | 6180 | 6257 | 6340 |
| 3840 | 5982 | 6023 | 6074 | 6135 | 6204 | 6281 | 6365 |
| 3904 | 6006 | 6047 | 6098 | 6159 | 6228 | 6305 | 6389 |
| 3968 | 6029 | 6070 | 6121 | 6182 | 6252 | 6329 | 6413 |
| 4032 | 6052 | 6093 | 6145 | 6205 | 6275 | 6352 | 6437 |
| 4096 | 6075 | 6116 | 6167 | 6228 | 6298 | 6376 | 6460 |
| 4160 | 6097 | 6139 | 6190 | 6251 | 6321 | 6399 | 6484 |
| 4224 | 6120 | 6161 | 6213 | 6274 | 6344 | 6421 | 6507 |
| 4288 | 6142 | 6183 | 6235 | 6296 | 6366 | 6444 | 6529 |
| 4352 | 6164 | 6205 | 6257 | 6318 | 6388 | 6466 | 6552 |
| 4416 | 6185 | 6227 | 6278 | 6340 | 6410 | 6488 | 6574 |
| 4480 | 6207 | 6248 | 6300 | 6361 | 6432 | 6510 | 6596 |
| 4544 | 6228 | 6269 | 6321 | 6383 | 6453 | 6532 | 6618 |
| 4608 | 6249 | 6290 | 6342 | 6404 | 6475 | 6553 | 6639 |
| 4672 | 6269 | 6311 | 6363 | 6425 | 6496 | 6575 | 6661 |
| 4736 | 6290 | 6332 | 6384 | 6446 | 6516 | 6596 | 6682 |
| 4800 | 6310 | 6352 | 6404 | 6466 | 6537 | 6616 | 6703 |
| 4864 | 6330 | 6372 | 6424 | 6486 | 6558 | 6637 | 6724 |
| 4928 | 6350 | 6392 | 6444 | 6507 | 6578 | 6657 | 6744 |
| 4992 | 6370 | 6412 | 6464 | 6527 | 6598 | 6678 | 6765 |
| 5056 | 6390 | 6431 | 6484 | 6546 | 6618 | 6698 | 6785 |
| 5120 | 6409 | 6451 | 6503 | 6566 | 6638 | 6718 | 6805 |
| 5184 | 6428 | 6470 | 6523 | 6585 | 6657 | 6737 | 6825 |
| 5248 | 6447 | 6489 | 6542 | 6605 | 6677 | 6757 | 6845 |
| 5312 | 6466 | 6508 | 6561 | 6624 | 6696 | 6776 | 6864 |
| 5376 | 6485 | 6527 | 6580 | 6643 | 6715 | 6795 | 6884 |
| 5440 | 6504 | 6546 | 6598 | 6661 | 6734 | 6815 | 6903 |
| 5504 | 6522 | 6564 | 6617 | 6680 | 6752 | 6833 | 6922 |
| 5568 | 6540 | 6582 | 6635 | 6699 | 6771 | 6852 | 6941 |
| 5632 | 6558 | 6600 | 6654 | 6717 | 6789 | 6871 | 6960 |
| 5696 | 6576 | 6618 | 6672 | 6735 | 6808 | 6890 | 6979 |
| 5760 | 6594 | 6636 | 6690 | 6753 | 6826 | 6907 | 6997 |
| 5824 | 6612 | 6654 | 6707 | 6771 | 6844 | 6925 | 7015 |
| 5888 | 6629 | 6672 | 6725 | 6789 | 6862 | 6944 | 7033 |
| 5952 | 6647 | 6689 | 6742 | 6806 | 6879 | 6961 | 7051 |
| 6016 | 6664 | 6706 | 6760 | 6824 | 6897 | 6979 | 7069 |
| 6080 | 6681 | 6723 | 6777 | 6841 | 6914 | 6997 | 7087 |
| 6144 | 6698 | 6741 | 6794 | 6858 | 6932 | 7014 | 7104 |
| 6208 | 6715 | 6757 | 6811 | 6875 | 6949 | 7031 | 7122 |
| 6272 | 6732 | 6774 | 6828 | 6892 | 6966 | 7049 | 7139 |
| 6336 | 6748 | 6791 | 6845 | 6909 | 6983 | 7066 | 7156 |
| 6400 | 6765 | 6807 | 6861 | 6926 | 7000 | 7083 | 7174 |
| 6464 | 6781 | 6824 | 6878 | 6942 | 7016 | 7100 | 7191 |
| 6528 | 6797 | 6840 | 6894 | 6959 | 7033 | 7116 | 7207 |
| 6592 | 6813 | 6856 | 6910 | 6975 | 7050 | 7133 | 7224 |
| 6656 | 6830 | 6872 | 6927 | 6991 | 7066 | 7149 | 7241 |
| 6720 | 6845 | 6888 | 6943 | 7007 | 7082 | 7166 | 7257 |
| 6784 | 6861 | 6904 | 6958 | 7023 | 7098 | 7182 | 7274 |

| | | | | | | | |
|-------|------|------|------|------|------|------|------|
| 6848 | 6877 | 6920 | 6974 | 7039 | 7114 | 7198 | 7290 |
| 6912 | 6892 | 6936 | 6990 | 7055 | 7130 | 7214 | 7306 |
| 6976 | 6908 | 6951 | 7006 | 7071 | 7146 | 7230 | 7322 |
| 7040 | 6923 | 6966 | 7021 | 7086 | 7162 | 7246 | 7338 |
| 7104 | 6939 | 6982 | 7036 | 7102 | 7177 | 7262 | 7354 |
| 7168 | 6954 | 6997 | 7052 | 7117 | 7193 | 7277 | 7370 |
| 7232 | 6969 | 7012 | 7067 | 7133 | 7208 | 7293 | 7386 |
| 7296 | 6984 | 7027 | 7082 | 7148 | 7223 | 7308 | 7401 |
| 7360 | 6999 | 7042 | 7097 | 7163 | 7239 | 7324 | 7417 |
| 7424 | 7014 | 7057 | 7112 | 7178 | 7254 | 7339 | 7432 |
| 7488 | 7028 | 7072 | 7127 | 7193 | 7269 | 7354 | 7447 |
| 7552 | 7043 | 7086 | 7141 | 7207 | 7284 | 7369 | 7462 |
| 7616 | 7057 | 7101 | 7156 | 7222 | 7298 | 7384 | 7478 |
| 7680 | 7072 | 7115 | 7171 | 7237 | 7313 | 7399 | 7493 |
| 7744 | 7086 | 7130 | 7185 | 7251 | 7328 | 7414 | 7507 |
| 7808 | 7100 | 7144 | 7199 | 7266 | 7342 | 7428 | 7522 |
| 7872 | 7114 | 7158 | 7214 | 7280 | 7357 | 7443 | 7537 |
| 7936 | 7129 | 7172 | 7228 | 7294 | 7371 | 7457 | 7552 |
| 8000 | 7143 | 7186 | 7242 | 7309 | 7386 | 7472 | 7566 |
| 8064 | 7156 | 7200 | 7256 | 7323 | 7400 | 7486 | 7581 |
| 8128 | 7170 | 7214 | 7270 | 7337 | 7414 | 7500 | 7595 |
| 8192 | 7184 | 7228 | 7284 | 7351 | 7428 | 7515 | 7609 |
| 8256 | 7198 | 7242 | 7298 | 7365 | 7442 | 7529 | 7624 |
| 8320 | 7211 | 7255 | 7311 | 7378 | 7456 | 7543 | 7638 |
| 8384 | 7225 | 7269 | 7325 | 7392 | 7470 | 7557 | 7652 |
| 8448 | 7238 | 7282 | 7338 | 7406 | 7483 | 7570 | 7666 |
| 8512 | 7252 | 7296 | 7352 | 7419 | 7497 | 7584 | 7680 |
| 8576 | 7265 | 7309 | 7365 | 7433 | 7511 | 7598 | 7694 |
| 8640 | 7278 | 7322 | 7379 | 7446 | 7524 | 7612 | 7708 |
| 8704 | 7291 | 7336 | 7392 | 7460 | 7538 | 7626 | 7721 |
| 8768 | 7304 | 7349 | 7405 | 7473 | 7551 | 7639 | 7735 |
| 8832 | 7317 | 7362 | 7418 | 7486 | 7564 | 7652 | 7748 |
| 8896 | 7330 | 7375 | 7431 | 7499 | 7578 | 7665 | 7762 |
| 8960 | 7343 | 7388 | 7444 | 7512 | 7591 | 7679 | 7775 |
| 9024 | 7356 | 7401 | 7457 | 7525 | 7604 | 7692 | 7789 |
| 9088 | 7369 | 7413 | 7470 | 7538 | 7617 | 7705 | 7802 |
| 9152 | 7382 | 7426 | 7483 | 7551 | 7630 | 7718 | 7815 |
| 9216 | 7394 | 7439 | 7496 | 7564 | 7643 | 7731 | 7828 |
| 9280 | 7407 | 7451 | 7508 | 7577 | 7656 | 7744 | 7841 |
| 9344 | 7419 | 7464 | 7521 | 7589 | 7668 | 7757 | 7854 |
| 9408 | 7432 | 7476 | 7533 | 7602 | 7681 | 7770 | 7867 |
| 9472 | 7444 | 7489 | 7546 | 7614 | 7694 | 7783 | 7880 |
| 9536 | 7456 | 7501 | 7558 | 7627 | 7706 | 7795 | 7893 |
| 9600 | 7468 | 7513 | 7571 | 7639 | 7719 | 7808 | 7906 |
| 9664 | 7481 | 7526 | 7583 | 7652 | 7731 | 7821 | 7919 |
| 9728 | 7493 | 7538 | 7595 | 7664 | 7744 | 7833 | 7931 |
| 9792 | 7505 | 7550 | 7607 | 7676 | 7756 | 7846 | 7944 |
| 9856 | 7517 | 7562 | 7619 | 7688 | 7768 | 7858 | 7956 |
| 9920 | 7529 | 7574 | 7631 | 7701 | 7781 | 7870 | 7969 |
| 9984 | 7541 | 7586 | 7643 | 7713 | 7793 | 7883 | 7981 |
| 10048 | 7553 | 7598 | 7655 | 7725 | 7805 | 7895 | 7994 |
| 10112 | 7564 | 7610 | 7667 | 7737 | 7817 | 7907 | 8006 |
| 10176 | 7576 | 7621 | 7679 | 7749 | 7829 | 7919 | 8018 |
| 10240 | 7588 | 7633 | 7691 | 7760 | 7841 | 7931 | 8030 |
| 10304 | 7599 | 7645 | 7703 | 7773 | 7853 | 7943 | 8042 |
| 10368 | 7611 | 7656 | 7714 | 7784 | 7865 | 7955 | 8055 |
| 10432 | 7622 | 7668 | 7726 | 7796 | 7876 | 7967 | 8067 |
| 10496 | 7634 | 7679 | 7737 | 7807 | 7888 | 7979 | 8078 |
| 10560 | 7645 | 7691 | 7749 | 7819 | 7900 | 7991 | 8090 |
| 10624 | 7657 | 7702 | 7760 | 7830 | 7911 | 8002 | 8102 |
| 10688 | 7668 | 7713 | 7772 | 7842 | 7923 | 8014 | 8114 |
| 10752 | 7679 | 7725 | 7783 | 7853 | 7935 | 8026 | 8126 |
| 10816 | 7690 | 7736 | 7794 | 7865 | 7946 | 8037 | 8138 |
| 10880 | 7702 | 7747 | 7806 | 7876 | 7957 | 8049 | 8149 |
| 10944 | 7713 | 7758 | 7817 | 7887 | 7969 | 8060 | 8161 |
| 11008 | 7724 | 7769 | 7828 | 7899 | 7980 | 8072 | 8172 |
| 11072 | 7735 | 7781 | 7839 | 7910 | 7991 | 8083 | 8184 |
| 11136 | 7746 | 7792 | 7851 | 7921 | 8003 | 8094 | 8195 |
| 11200 | 7757 | 7803 | 7861 | 7932 | 8014 | 8106 | 8207 |
| 11264 | 7767 | 7813 | 7872 | 7943 | 8025 | 8117 | 8218 |
| 11328 | 7778 | 7824 | 7883 | 7954 | 8036 | 8128 | 8229 |
| 11392 | 7789 | 7835 | 7894 | 7965 | 8047 | 8139 | 8241 |
| 11456 | 7800 | 7846 | 7905 | 7976 | 8058 | 8150 | 8252 |
| 11520 | 7811 | 7857 | 7916 | 7987 | 8069 | 8161 | 8263 |
| 11584 | 7821 | 7867 | 7926 | 7997 | 8080 | 8173 | 8274 |
| 11648 | 7832 | 7878 | 7937 | 8008 | 8091 | 8183 | 8285 |
| 11712 | 7842 | 7889 | 7948 | 8019 | 8102 | 8194 | 8296 |
| 11776 | 7853 | 7899 | 7958 | 8030 | 8112 | 8205 | 8307 |
| 11840 | 7863 | 7910 | 7969 | 8040 | 8123 | 8216 | 8318 |
| 11904 | 7874 | 7920 | 7980 | 8051 | 8134 | 8227 | 8329 |
| 11968 | 7884 | 7931 | 7990 | 8062 | 8145 | 8238 | 8340 |
| 12032 | 7895 | 7941 | 8001 | 8072 | 8155 | 8248 | 8350 |
| 12096 | 7905 | 7951 | 8011 | 8083 | 8166 | 8259 | 8362 |
| 12160 | 7915 | 7962 | 8021 | 8093 | 8176 | 8270 | 8372 |
| 12224 | 7925 | 7972 | 8032 | 8104 | 8187 | 8280 | 8383 |
| 12288 | 7936 | 7982 | 8042 | 8114 | 8197 | 8291 | 8394 |
| 12352 | 7946 | 7992 | 8052 | 8124 | 8208 | 8301 | 8404 |
| 12416 | 7956 | 8003 | 8062 | 8135 | 8218 | 8312 | 8415 |
| 12480 | 7966 | 8013 | 8073 | 8145 | 8228 | 8322 | 8426 |
| 12544 | 7976 | 8023 | 8083 | 8155 | 8239 | 8333 | 8436 |
| 12608 | 7986 | 8033 | 8093 | 8165 | 8249 | 8343 | 8446 |
| 12672 | 7996 | 8043 | 8103 | 8175 | 8259 | 8353 | 8457 |
| 12736 | 8006 | 8053 | 8113 | 8185 | 8269 | 8364 | 8467 |
| 12800 | 8016 | 8063 | 8123 | 8195 | 8279 | 8374 | 8478 |
| 12864 | 8026 | 8073 | 8133 | 8205 | 8289 | 8384 | 8488 |
| 12928 | 8036 | 8082 | 8143 | 8215 | 8300 | 8394 | 8498 |
| 12992 | 8045 | 8092 | 8153 | 8225 | 8310 | 8404 | 8505 |
| 13056 | 8055 | 8102 | 8162 | 8235 | 8320 | 8414 | 8519 |
| 13120 | 8065 | 8112 | 8172 | 8245 | 8330 | 8424 | 8529 |
| 13184 | 8074 | 8122 | 8182 | 8255 | 8340 | 8435 | 8539 |
| 13248 | 8084 | 8131 | 8192 | 8265 | 8349 | 8444 | 8549 |
| 13312 | 8094 | 8141 | 8201 | 8275 | 8359 | 8454 | 8559 |
| 13376 | 8103 | 8150 | 8211 | 8284 | 8369 | 8464 | 8569 |
| 13440 | 8113 | 8160 | 8221 | 8294 | 8379 | 8474 | 8579 |
| 13504 | 8122 | 8170 | 8230 | 8304 | 8389 | 8484 | 8589 |
| 13568 | 8132 | 8179 | 8240 | 8313 | 8398 | 8494 | 8599 |
| 13632 | 8141 | 8189 | 8249 | 8323 | 8408 | 8504 | 8609 |
| 13696 | 8151 | 8198 | 8259 | 8333 | 8418 | 8513 | 8619 |
| 13760 | 8160 | 8207 | 8268 | 8342 | 8427 | 8523 | 8629 |
| 13824 | 8169 | 8217 | 8278 | 8352 | 8437 | 8533 | 8639 |
| 13888 | 8179 | 8226 | 8287 | 8361 | 8446 | 8542 | 8649 |
| 13952 | 8188 | 8236 | 8297 | 8370 | 8455 | 8552 | 8659 |

HTPA16x16dL1.6/0.8 SMD

Thermopile Array With Lens Optics

Rev.0: 2016.05.04 Schnorr




| | | | | | | | |
|-------|------|------|------|------|------|------|------|
| 14016 | 8197 | 8245 | 8306 | 8380 | 8465 | 8562 | 8667 |
| 14080 | 8206 | 8254 | 8315 | 8389 | 8475 | 8571 | 8677 |
| 14144 | 8216 | 8263 | 8325 | 8399 | 8484 | 8581 | 8687 |
| 14208 | 8225 | 8272 | 8334 | 8408 | 8494 | 8590 | 8696 |
| 14272 | 8234 | 8282 | 8343 | 8417 | 8503 | 8600 | 8706 |
| 14336 | 8243 | 8291 | 8352 | 8426 | 8512 | 8609 | 8715 |
| 14400 | 8252 | 8300 | 8361 | 8436 | 8522 | 8618 | 8725 |
| 14464 | 8261 | 8309 | 8371 | 8445 | 8531 | 8628 | 8734 |
| 14528 | 8270 | 8318 | 8380 | 8454 | 8540 | 8637 | 8744 |
| 14592 | 8279 | 8327 | 8389 | 8463 | 8549 | 8646 | 8753 |
| 14656 | 8288 | 8336 | 8398 | 8472 | 8559 | 8656 | 8762 |
| 14720 | 8297 | 8345 | 8407 | 8481 | 8568 | 8665 | 8772 |
| 14784 | 8306 | 8354 | 8416 | 8490 | 8577 | 8674 | 8781 |
| 14848 | 8315 | 8363 | 8425 | 8499 | 8586 | 8683 | 8790 |
| 14912 | 8323 | 8372 | 8434 | 8508 | 8595 | 8692 | 8800 |
| 14976 | 8332 | 8380 | 8442 | 8517 | 8604 | 8702 | 8809 |
| 15040 | 8341 | 8389 | 8451 | 8526 | 8613 | 8711 | 8819 |
| 15104 | 8350 | 8398 | 8460 | 8535 | 8622 | 8720 | 8827 |
| 15168 | 8358 | 8407 | 8469 | 8544 | 8631 | 8729 | 8836 |
| 15232 | 8367 | 8416 | 8478 | 8553 | 8640 | 8738 | 8845 |
| 15296 | 8376 | 8424 | 8487 | 8562 | 8649 | 8747 | 8855 |
| 15360 | 8384 | 8433 | 8495 | 8570 | 8658 | 8756 | 8864 |
| 15424 | 8393 | 8442 | 8504 | 8579 | 8666 | 8765 | 8873 |
| 15488 | 8402 | 8450 | 8513 | 8588 | 8675 | 8774 | 8882 |
| 15552 | 8410 | 8459 | 8521 | 8597 | 8684 | 8782 | 8891 |
| 15616 | 8419 | 8467 | 8530 | 8605 | 8693 | 8791 | 8900 |
| 15680 | 8427 | 8476 | 8538 | 8614 | 8702 | 8800 | 8908 |
| 15744 | 8436 | 8484 | 8547 | 8623 | 8710 | 8809 | 8917 |
| 15808 | 8444 | 8493 | 8556 | 8631 | 8719 | 8818 | 8926 |
| 15872 | 8453 | 8501 | 8564 | 8640 | 8728 | 8826 | 8935 |
| 15936 | 8461 | 8510 | 8573 | 8648 | 8736 | 8835 | 8944 |
| 16000 | 8469 | 8518 | 8581 | 8657 | 8745 | 8844 | 8953 |
| 16064 | 8478 | 8527 | 8590 | 8665 | 8753 | 8852 | 8961 |
| 16128 | 8486 | 8535 | 8598 | 8674 | 8762 | 8861 | 8970 |
| 16192 | 8494 | 8543 | 8606 | 8682 | 8771 | 8870 | 8979 |
| 16256 | 8503 | 8552 | 8615 | 8691 | 8779 | 8878 | 8988 |
| 16320 | 8511 | 8560 | 8623 | 8699 | 8788 | 8887 | 8996 |
| 16384 | 8519 | 8568 | 8631 | 8708 | 8796 | 8895 | 9005 |
| 16448 | 8527 | 8577 | 8640 | 8716 | 8804 | 8904 | 9013 |
| 16512 | 8536 | 8585 | 8648 | 8724 | 8813 | 8912 | 9022 |
| 16576 | 8544 | 8593 | 8656 | 8733 | 8821 | 8921 | 9031 |
| 16640 | 8552 | 8601 | 8664 | 8741 | 8830 | 8929 | 9039 |
| 16704 | 8560 | 8609 | 8673 | 8749 | 8838 | 8938 | 9048 |
| 16768 | 8568 | 8617 | 8681 | 8757 | 8846 | 8946 | 9056 |
| 16832 | 8576 | 8626 | 8689 | 8766 | 8854 | 8954 | 9065 |
| 16896 | 8584 | 8634 | 8697 | 8774 | 8863 | 8963 | 9073 |
| 16960 | 8592 | 8642 | 8705 | 8782 | 8871 | 8971 | 9081 |
| 17024 | 8600 | 8650 | 8713 | 8790 | 8879 | 8979 | 9090 |
| 17088 | 8608 | 8658 | 8721 | 8798 | 8887 | 8988 | 9098 |
| 17152 | 8616 | 8666 | 8729 | 8806 | 8896 | 8996 | 9106 |
| 17216 | 8624 | 8674 | 8737 | 8814 | 8904 | 9004 | 9115 |
| 17280 | 8632 | 8682 | 8745 | 8822 | 8912 | 9012 | 9125 |
| 17344 | 8640 | 8690 | 8753 | 8831 | 8920 | 9021 | 9131 |
| 17408 | 8648 | 8697 | 8761 | 8839 | 8928 | 9029 | 9140 |
| 17472 | 8656 | 8705 | 8769 | 8847 | 8936 | 9037 | 9148 |
| 17536 | 8664 | 8713 | 8777 | 8854 | 8944 | 9045 | 9156 |
| 17600 | 8671 | 8721 | 8785 | 8862 | 8952 | 9053 | 9164 |
| 17664 | 8679 | 8729 | 8793 | 8870 | 8960 | 9061 | 9172 |
| 17728 | 8687 | 8737 | 8801 | 8878 | 8968 | 9069 | 9181 |
| 17792 | 8695 | 8745 | 8809 | 8886 | 8976 | 9077 | 9189 |
| 17856 | 8702 | 8752 | 8816 | 8894 | 8984 | 9085 | 9196 |
| 17920 | 8710 | 8760 | 8824 | 8902 | 8992 | 9093 | 9206 |
| 17984 | 8718 | 8768 | 8832 | 8910 | 9000 | 9101 | 9213 |
| 18048 | 8725 | 8775 | 8840 | 8917 | 9008 | 9109 | 9221 |
| 18112 | 8733 | 8783 | 8847 | 8925 | 9016 | 9117 | 9229 |
| 18176 | 8741 | 8791 | 8855 | 8933 | 9023 | 9125 | 9237 |
| 18240 | 8748 | 8798 | 8863 | 8941 | 9031 | 9133 | 9245 |
| 18304 | 8756 | 8806 | 8871 | 8949 | 9039 | 9141 | 9253 |
| 18368 | 8764 | 8814 | 8879 | 8956 | 9047 | 9149 | 9261 |
| 18432 | 8771 | 8821 | 8886 | 8964 | 9055 | 9157 | 9269 |
| 18496 | 8779 | 8829 | 8893 | 8972 | 9062 | 9164 | 9277 |
| 18560 | 8786 | 8836 | 8901 | 8979 | 9070 | 9172 | 9286 |
| 18624 | 8794 | 8844 | 8909 | 8987 | 9078 | 9180 | 9292 |
| 18688 | 8801 | 8851 | 8916 | 8994 | 9085 | 9188 | 9300 |
| 18752 | 8808 | 8859 | 8924 | 9002 | 9093 | 9195 | 9308 |
| 18816 | 8816 | 8866 | 8931 | 9010 | 9101 | 9203 | 9316 |
| 18880 | 8823 | 8874 | 8939 | 9017 | 9108 | 9211 | 9324 |
| 18944 | 8831 | 8881 | 8946 | 9024 | 9116 | 9218 | 9331 |
| 19008 | 8838 | 8889 | 8954 | 9032 | 9123 | 9226 | 9339 |
| 19072 | 8845 | 8896 | 8961 | 9040 | 9131 | 9234 | 9347 |
| 19136 | 8853 | 8903 | 8968 | 9047 | 9138 | 9241 | 9354 |
| 19200 | 8860 | 8911 | 8976 | 9055 | 9146 | 9249 | 9362 |
| 19264 | 8867 | 8918 | 8983 | 9062 | 9153 | 9256 | 9370 |
| 19328 | 8875 | 8925 | 8991 | 9069 | 9161 | 9264 | 9377 |
| 19392 | 8882 | 8933 | 8998 | 9077 | 9168 | 9272 | 9385 |
| 19456 | 8889 | 8940 | 9005 | 9084 | 9176 | 9279 | 9393 |
| 19520 | 8896 | 8947 | 9013 | 9092 | 9183 | 9282 | 9401 |
| 19584 | 8904 | 8954 | 9020 | 9099 | 9191 | 9294 | 9408 |
| 19648 | 8911 | 8962 | 9027 | 9106 | 9198 | 9302 | 9415 |
| 19712 | 8918 | 8969 | 9034 | 9114 | 9205 | 9309 | 9423 |
| 19776 | 8925 | 8976 | 9042 | 9121 | 9213 | 9316 | 9430 |
| 19840 | 8932 | 8983 | 9048 | 9128 | 9220 | 9324 | 9438 |
| 19904 | 8939 | 8990 | 9056 | 9135 | 9228 | 9331 | 9445 |
| 19968 | 8947 | 8998 | 9063 | 9143 | 9235 | 9339 | 9453 |
| 20032 | 8954 | 9005 | 9070 | 9150 | 9242 | 9346 | 9460 |
| 20096 | 8961 | 9012 | 9077 | 9157 | 9249 | 9353 | 9468 |
| 20160 | 8968 | 9019 | 9085 | 9164 | 9257 | 9361 | 9475 |
| 20224 | 8976 | 9026 | 9092 | 9171 | 9264 | 9368 | 9483 |
| 20288 | 8982 | 9033 | 9099 | 9179 | 9271 | 9375 | 9490 |
| 20352 | 8989 | 9040 | 9106 | 9186 | 9278 | 9383 | 9497 |
| 20416 | 8996 | 9047 | 9113 | 9193 | 9285 | 9390 | 9505 |
| 20480 | 9003 | 9054 | 9120 | 9200 | 9293 | 9397 | 9512 |
| 20544 | 9010 | 9061 | 9127 | 9207 | 9300 | 9404 | 9519 |
| 20608 | 9017 | 9068 | 9134 | 9214 | 9307 | 9411 | 9527 |
| 20672 | 9024 | 9075 | 9141 | 9221 | 9314 | 9419 | 9534 |
| 20736 | 9031 | 9082 | 9148 | 9228 | 9321 | 9426 | 9541 |
| 20800 | 9038 | 9089 | 9155 | 9235 | 9328 | 9433 | 9548 |
| 20864 | 9044 | 9096 | 9162 | 9242 | 9335 | 9440 | 9555 |
| 20928 | 9051 | 9103 | 9169 | 9249 | 9342 | 9447 | 9563 |
| 20992 | 9058 | 9110 | 9176 | 9256 | 9349 | 9454 | 9570 |
| 21056 | 9065 | 9116 | 9183 | 9263 | 9356 | 9461 | 9577 |
| 21120 | 9072 | 9123 | 9190 | 9270 | 9363 | 9469 | 9584 |
| 21184 | 9079 | 9130 | 9197 | 9277 | 9370 | 9476 | 9591 |
| 21248 | 9085 | 9137 | 9203 | 9284 | 9377 | 9483 | 9598 |
| 21312 | 9092 | 9144 | 9210 | 9291 | 9384 | 9490 | 9606 |
| 21376 | 9099 | 9151 | 9217 | 9298 | 9391 | 9497 | 9613 |
| 21440 | 9106 | 9157 | 9224 | 9305 | 9398 | 9504 | 9620 |
| 21504 | 9112 | 9164 | 9231 | 9311 | 9405 | 9511 | 9627 |
| 21568 | 9119 | 9171 | 9238 | 9318 | 9412 | 9518 | 9634 |
| 21632 | 9126 | 9178 | 9244 | 9325 | 9419 | 9525 | 9641 |
| 21696 | 9132 | 9184 | 9251 | 9332 | 9426 | 9532 | 9648 |
| 21760 | 9139 | 9191 | 9258 | 9339 | 9433 | 9538 | 9655 |
| 21824 | 9146 | 9198 | 9264 | 9345 | 9439 | 9545 | 9662 |
| 21888 | 9152 | 9204 | 9271 | 9352 | 9446 | 9552 | 9669 |

| | | | | | | | |
|-------|------|------|-------|-------|-------|-------|-------|
| 21952 | 9159 | 9211 | 9278 | 9359 | 9453 | 9559 | 9676 |
| 22016 | 9166 | 9218 | 9285 | 9366 | 9460 | 9566 | 9683 |
| 22080 | 9172 | 9224 | 9291 | 9372 | 9467 | 9573 | 9690 |
| 22144 | 9179 | 9231 | 9298 | 9379 | 9473 | 9580 | 9697 |
| 22208 | 9185 | 9237 | 9305 | 9386 | 9480 | 9586 | 9703 |
| 22272 | 9192 | 9244 | 9311 | 9393 | 9487 | 9593 | 9710 |
| 22336 | 9199 | 9251 | 9318 | 9399 | 9494 | 9600 | 9717 |
| 22400 | 9205 | 9257 | 9324 | 9406 | 9500 | 9607 | 9724 |
| 22464 | 9212 | 9264 | 9331 | 9412 | 9507 | 9614 | 9731 |
| 22528 | 9218 | 9270 | 9338 | 9419 | 9514 | 9620 | 9738 |
| 22592 | 9225 | 9277 | 9344 | 9426 | 9520 | 9627 | 9745 |
| 22656 | 9231 | 9283 | 9351 | 9432 | 9527 | 9634 | 9751 |
| 22720 | 9237 | 9290 | 9357 | 9439 | 9534 | 9641 | 9758 |
| 22784 | 9244 | 9296 | 9364 | 9445 | 9540 | 9647 | 9765 |
| 22848 | 9250 | 9303 | 9370 | 9452 | 9547 | 9654 | 9772 |
| 22912 | 9257 | 9309 | 9377 | 9458 | 9554 | 9661 | 9778 |
| 22976 | 9263 | 9316 | 9383 | 9465 | 9560 | 9667 | 9785 |
| 23040 | 9270 | 9322 | 9390 | 9472 | 9567 | 9674 | 9792 |
| 23104 | 9276 | 9328 | 9396 | 9478 | 9573 | 9680 | 9799 |
| 23168 | 9282 | 9335 | 9402 | 9485 | 9580 | 9687 | 9805 |
| 23232 | 9289 | 9341 | 9409 | 9491 | 9586 | 9694 | 9812 |
| 23296 | 9295 | 9348 | 9415 | 9497 | 9593 | 9700 | 9819 |
| 23360 | 9301 | 9354 | 9422 | 9504 | 9599 | 9707 | 9825 |
| 23424 | 9308 | 9360 | 9428 | 9510 | 9606 | 9713 | 9832 |
| 23488 | 9314 | 9367 | 9434 | 9517 | 9612 | 9720 | 9838 |
| 23552 | 9320 | 9373 | 9441 | 9523 | 9619 | 9726 | 9845 |
| 23616 | 9327 | 9379 | 9447 | 9530 | 9625 | 9733 | 9852 |
| 23680 | 9333 | 9385 | 9453 | 9536 | 9632 | 9739 | 9858 |
| 23744 | 9339 | 9392 | 9460 | 9542 | 9638 | 9746 | 9865 |
| 23808 | 9345 | 9398 | 9466 | 9549 | 9644 | 9752 | 9871 |
| 23872 | 9351 | 9404 | 9472 | 9555 | 9651 | 9759 | 9878 |
| 23936 | 9358 | 9410 | 9479 | 9561 | 9657 | 9765 | 9884 |
| 24000 | 9364 | 9417 | 9485 | 9568 | 9664 | 9772 | 9891 |
| 24064 | 9370 | 9423 | 9491 | 9574 | 9670 | 9778 | 9897 |
| 24128 | 9376 | 9429 | 9497 | 9580 | 9676 | 9784 | 9904 |
| 24192 | 9382 | 9435 | 9504 | 9586 | 9683 | 9791 | 9910 |
| 24256 | 9389 | 9442 | 9510 | 9593 | 9689 | 9797 | 9917 |
| 24320 | 9395 | 9448 | 9516 | 9599 | 9695 | 9804 | 9923 |
| 24384 | 9401 | 9454 | 9522 | 9605 | 9702 | 9810 | 9930 |
| 24448 | 9407 | 9460 | 9528 | 9611 | 9708 | 9816 | 9936 |
| 24512 | 9413 | 9466 | 9535 | 9618 | 9714 | 9823 | 9943 |
| 24576 | 9419 | 9472 | 9541 | 9624 | 9720 | 9829 | 9949 |
| 24640 | 9425 | 9478 | 9547 | 9630 | 9726 | 9835 | 9956 |
| 24704 | 9431 | 9484 | 9553 | 9636 | 9733 | 9842 | 9962 |
| 24768 | 9437 | 9491 | 9559 | 9642 | 9739 | 9848 | 9968 |
| 24832 | 9443 | 9497 | 9565 | 9649 | 9745 | 9854 | 9974 |
| 24896 | 9449 | 9503 | 9571 | 9655 | 9752 | 9861 | 9981 |
| 24960 | 9455 | 9509 | 9578 | 9661 | 9758 | 9867 | 9987 |
| 25024 | 9461 | 9515 | 9584 | 9667 | 9764 | 9873 | 9993 |
| 25088 | 9467 | 9521 | 9590 | 9673 | 9770 | 9879 | 10000 |
| 25152 | 9473 | 9527 | 9596 | 9679 | 9776 | 9886 | 10006 |
| 25216 | 9479 | 9532 | 9600 | 9685 | 9782 | 9892 | 10012 |
| 25280 | 9485 | 9539 | 9608 | 9691 | 9789 | 9898 | 10018 |
| 25344 | 9491 | 9545 | 9614 | 9697 | 9795 | 9904 | 10025 |
| 25408 | 9497 | 9551 | 9620 | 9704 | 9801 | 9910 | 10031 |
| 25472 | 9503 | 9557 | 9626 | 9710 | 9807 | 9916 | 10037 |
| 25536 | 9508 | 9563 | 9632 | 9716 | 9813 | 9923 | 10043 |
| 25600 | 9515 | 9569 | 9638 | 9722 | 9819 | 9929 | 10050 |
| 25664 | 9521 | 9575 | 9644 | 9728 | 9825 | 9935 | 10056 |
| 25728 | 9527 | 9580 | 9650 | 9734 | 9831 | 9941 | 10062 |
| 25792 | 9533 | 9586 | 9656 | 9739 | 9837 | 9947 | 10068 |
| 25856 | 9539 | 9592 | 9662 | 9746 | 9843 | 9953 | 10074 |
| 25920 | 9544 | 9598 | 9667 | 9752 | 9849 | 9959 | 10080 |
| 25984 | 9550 | 9604 | 9673 | 9757 | 9855 | 9965 | 10087 |
| 26048 | 9556 | 9610 | 9679 | 9763 | 9861 | 9971 | 10093 |
| 26112 | 9562 | 9616 | 9685 | 9769 | 9867 | 9977 | 10099 |
| 26176 | 9568 | 9622 | 9691 | 9775 | 9873 | 9983 | 10105 |
| 26240 | 9574 | 9627 | 9697 | 9781 | 9879 | 9989 | 10111 |
| 26304 | 9579 | 9633 | 9703 | 9787 | 9885 | 9995 | 10117 |
| 26368 | 9585 | 9639 | 9709 | 9793 | 9891 | 10002 | 10123 |
| 26432 | 9591 | 9645 | 9714 | 9799 | 9897 | 10007 | 10129 |
| 26496 | 9597 | 9651 | 9720 | 9805 | 9903 | 10013 | 10135 |
| 26560 | 9602 | 9656 | 9726 | 9811 | 9909 | 10019 | 10141 |
| 26624 | 9608 | 9662 | 9732 | 9816 | 9915 | 10025 | 10147 |
| 26688 | 9614 | 9668 | 9738 | 9822 | 9921 | 10031 | 10153 |
| 26752 | 9620 | 9674 | 9743 | 9828 | 9926 | 10037 | 10159 |
| 26816 | 9625 | 9679 | 9749 | 9834 | 9932 | 10043 | 10165 |
| 26880 | 9631 | 9685 | 9759 | 9840 | 9940 | 10050 | 10171 |
| 26944 | 9637 | 9691 | 9761 | 9846 | 9944 | 10055 | 10177 |
| 27008 | 9642 | 9696 | 9766 | 9851 | 9950 | 10061 | 10183 |
| 27072 | 9648 | 9702 | 9772 | 9857 | 9956 | 10067 | 10189 |
| 27136 | 9654 | 9708 | 9778 | 9863 | 9962 | 10073 | 10195 |
| 27200 | 9659 | 9714 | 9784 | 9869 | 9967 | 10079 | 10201 |
| 27264 | 9665 | 9719 | 9789 | 9874 | 9973 | 10084 | 10207 |
| 27328 | 9671 | 9725 | 9795 | 9880 | 9979 | 10090 | 10213 |
| 27392 | 9676 | 9730 | 9801 | 9886 | 9985 | 10095 | 10219 |
| 27456 | 9682 | 9736 | 9806 | 9890 | 9990 | 10102 | 10225 |
| 27520 | 9687 | 9742 | 9812 | 9897 | 9996 | 10108 | 10231 |
| 27584 | 9693 | 9747 | 9818 | 9903 | 10002 | 10114 | 10237 |
| 27648 | 9699 | 9753 | 9823 | 9909 | 10008 | 10119 | 10242 |
| 27712 | 9704 | 9759 | 9829 | 9914 | 10013 | 10125 | 10248 |
| 27776 | 9710 | 9764 | 9835 | 9920 | 10019 | 10131 | 10254 |
| 27840 | 9715 | 9770 | 9840 | 9926 | 10025 | 10137 | 10260 |
| 27904 | 9721 | 9775 | 9846 | 9931 | 10031 | 10142 | 10266 |
| 27968 | 9726 | 9781 | 9851 | 9937 | 10038 | 10148 | 10272 |
| 28032 | 9732 | 9786 | 9857 | 9943 | 10043 | 10154 | 10278 |
| 28096 | 9737 | 9792 | 9863 | 9948 | 10048 | 10160 | 10283 |
| 28160 | 9743 | 9797 | 9868 | 9954 | 10053 | 10165 | 10289 |
| 28224 | 9748 | 9803 | 9874 | 9959 | 10059 | 10171 | 10295 |
| 28288 | 9754 | 9809 | 9879 | 9965 | 10065 | 10177 | 10300 |
| 28352 | 9759 | 9814 | 9885 | 9971 | 10070 | 10182 | 10306 |
| 28416 | 9765 | 9819 | 9890 | 9976 | 10076 | 10188 | 10312 |
| 28480 | 9770 | 9825 | 9896 | 9982 | 10081 | 10194 | 10318 |
| 28544 | 9776 | 9831 | 9901 | 9987 | 10087 | 10199 | 10324 |
| 28608 | 9781 | 9836 | 9907 | 9993 | 10093 | 10205 | 10329 |
| 28672 | 9787 | 9841 | 9912 | 9998 | 10098 | 10211 | 10335 |
| 28736 | 9792 | 9847 | 9918 | 10004 | 10104 | 10216 | 10341 |
| 28800 | 9797 | 9852 | 9923 | 10009 | 10109 | 10222 | 10346 |
| 28864 | 9803 | 9858 | 9929 | 10015 | 10115 | 10228 | 10352 |
| 28928 | 9808 | 9863 | 9934 | 10020 | 10120 | 10233 | 10358 |
| 28992 | 9814 | 9869 | 9940 | 10026 | 10126 | 10239 | 10363 |
| 29056 | 9819 | 9874 | 9945 | 10031 | 10131 | 10244 | 10369 |
| 29120 | 9825 | 9879 | 9950 | 10037 | 10137 | 10250 | 10374 |
| 29184 | 9830 | 9885 | 9956 | 10042 | 10143 | 10256 | 10380 |
| 29248 | 9835 | 9890 | 9961 | 10048 | 10148 | 10261 | 10386 |
| 29312 | 9840 | 9895 | 9967 | 10053 | 10154 | 10267 | 10391 |
| 29376 | 9846 | 9901 | 9972 | 10059 | 10159 | 10272 | 10397 |
| 29440 | 9851 | 9906 | 9977 | 10064 | 10164 | 10278 | 10403 |
| 29504 | 9856 | 9912 | 9983 | 10069 | 10170 | 10283 | 10408 |
| 29568 | 9862 | 9917 | 9988 | 10075 | 10175 | 10289 | 10414 |
| 29632 | 9867 | 9922 | 9994 | 10080 | 10181 | 10294 | 10419 |
| 29696 | 9872 | 9927 | 9999 | 10086 | 10186 | 10299 | 10424 |
| 29760 | 9878 | 9933 | 10004 | 10091 | 10192 | 10305 | 10430 |
| 29824 | 9883 | 9938 | 10010 | 10096 | 10197 | 10311 | 10436 |

8 Outer Dimensions:

1



HEIMANN Sensor GmbH Contact / Customer Support
 Maria-Reiche-Str. 1 Phone 49 (0) 6123 60 50 30
 D-01109 Dresden / Germany Fax 49 (0) 6123 60 50 39

Internet
www.heimannsensor.com
 mail: info@heimannsensor.com